

## Axiwi AT-320M Submaster User Manual

### Version: Submaster

With this software, you have to setup 1 unit as a master. The other units can be free of choice as “Follower” and “Submaster”.



#### Set up as Master

1. Push and hold the **volume +** button
2. Then push the ‘on/off’ button (approx. 1-2 seconds) while pushing the **volume +** button at the same time. The colour of the LED-light indicates the channel. The AXIWI unit is set up in the ‘Master’ mode. The LED light will light up constantly

#### Set up as Submaster

1. Push and hold the **Volume –** button.
2. Then push the ‘on/off’ button (approx. 1-2 seconds) while pushing the **volume -** button at the same time.
3. The AXIWI unit is set up as “submaster”.  
The LED-light of the chosen channel will flash quickly.
4. The LED light will flash quicker than in the ‘Follower’ mode.

#### Set up as Follower

5. Push the ‘on /off’ button (at least 2 sec.); The LED-light of the chosen channel will flash.
6. With the ‘S’ button on the front, the speaking function can be activated and deactivated.
7. Press the ‘S’ button briefly to activate (and again) to deactivate the speaking function.
8. When the speaking function is activated, the LED-light of the chosen channel will flash,
9. the other LED-lights will light up constantly.

#### Change the channel

1. Push the volume up **+** button and hold it.
2. Push the ‘**S**’ button briefly at the same time. Each time you push the ‘S’ button, the LED light will change to the next colour; the next channel.

